

# MONTREAL PANORMA™

## WITH DENVER E-RIBBON BASIC BURNER



Using the CEVB (Controlled Ethanol Vapour Burning) technology, DecoFlame has created Montreal Panorama with the Denver e-Ribbon Basic burner, a simplified automatic burner with an unique built-in casing.

Featuring the e-Ribbon Fire™ burning system, it is suitable where safety and ease of use are in focus.

The info below is an example for a size 2000x400x380mm with a 1120 Denver e-Ribbon Basic burner.

Montreal Panorama can also be ordered as MTM with either a manual burner or the Denver e-Ribbon burner.

### CASING STANDARD FINISH



Black

### CASING FINISH ON REQUEST



RAL



Brushed stainless steel

### TECHNICAL INFORMATION


Capacity:	7.2L
Burning time:	7.3-20 hours (Depending on flame intensity)
Heat efficiency:	2.1 - 5.7 kW/h
Minimum room size:	115m <sup>3</sup>
Burner:	Denver e-Ribbon Basic 1120
Flametray:	900mm - aluminium
Casing standard:	Black powder coated aluminium, 8mm
Casing other finish on request :	RAL / brushed stainless steel
Topplate standard:	Powder coated black
Glass:	Hardened diamond clear glass
Power supply:	220V - 240V / 50 Hz
Fuel:	Use bioethanol at 96.5 - 97.5%

### FEATURES


- e-Ribbon™ technology
- Safety Sensors / Safety Chamber
- Fuel Level Indicator / Flame Level Indicator
- Remote control
- Bluetooth / App
- 6 flame levels (1-5 + ECO-Wave)
- No chimney required - no smoke, ash or soot

### BIOETHANOL

For use and information about bioethanol, please visit our website [decoflame.com](http://decoflame.com).  
(Please be aware that bioethanol is essential to a proper use and guarantee of your product).



# DENVER E-RIBBON BASIC BURNER



## Operating:

Step 1	Turn on the electronics of your Denver e-Ribbon Basic™ by pressing the  button.
Step 2	Fill in the right amount of bioethanol in the fuel tank by verifying the level on the fuel level indicator.
Step 3	To ignite the fireplace: Press the  button on the control panel. After about 3 minutes, the first flames will appear around the centre of the flame tray.
Step 4	When the filament no longer is red/glows (approx. 10 min) it is possible to adjust the flames.
Step 5	To switch off the fire at any time – also during the warming-up phase – press the  button on the control panel. The flames will disappear within few minutes.



Use the supplied remote control or download the DecoFlame App to your mobile device for controlling the biofireplace.

## Installation of DecoFlame App to the Denver e-Ribbon Basic burner




App Store



Google play


Model:	Denver Basic 720 - black	CE
Dimensions:	720x215x125mm - Flame Tray 500	
Power Supply:	220/240V - 50Hz must be earthed	
Serial Number:	7200005.16.V1.001	
Thermal Output:	max 2.9 kW	
Fuel Type:	bioethanol 96%	
Room Volume:	min. 58 m³	
Radio Frequency:	433.92 MHz	
Bluetooth Code:	0001	
Manufacturer:	DecoFlame ApS - Made in Denmark	




1. Download and install the DecoFlame App corresponding to your smart device's operating system. For more information go to: [decoflame.com](http://decoflame.com).

2. In order to pair your fireplace with your smart device, start the fireplace by pressing the 'ON' button.  
Start the App and choose your fireplace.  
Insert the code from YOUR rating plate, like the one highlighted above.

3. Once your device is paired, the fireplace should be visible on the app.  
You are now able to change the name of the fireplace.



4. Once you have selected your fireplace, you can turn it on by pressing 'START'.  
If the fireplace has already been turned on using the control panel, you can now monitor the fuel level and the consumption.



5. For the 'Turn Off Timer' press the clock icon in the lower right corner. To adjust the remaining time, slide the dot to the left and right and select 'SET TIMER'.  
The remaining burning time can be changed by repeating the above mentioned steps. To cancel the timer select 'CLEAR TIMER'.



6. For adjusting the flame intensity, select the desired level on the left side of the screen. (1-lowest and depending on model 5-highest + Eco-Wave or 6-highest). Should there not be enough fuel for the selected burning time - the fireplace will shut down automatically. Select 'STOP' to turn off the fireplace.